

Instruction Manual

RT201, RT207 and RT111 Table Clamp Magnifying Lamp

1. Securely fasten the table clamp included to a solid horizontal surface with thicknesses between 12.5 - 62.5mm (0.5 - 2.5"). Ideal for household tables, study desks and work benches



2. Insert the stem of the lamp into the clamp hole



3. Insert the 220v or 240v plug into a conveniently located electrical socket

4. Switch the lamp on by using the on/off switch located on top of the head. The lamp is now ready to use.

5. Adjust your lamp head position to suit your need and tighten the locking nuts as required

IMPORTANT! - SAFETY INSTRUCTIONS WARNING: When using electrical products, important safety precautions must be adhered to in order to reduce the risk of fire, electric shock and personal injury. PLEASE READ THE FOLLOWING CAREFULLY:

1. Indoor use only: a. Room temperature from -20 to +40 degrees centigrade b. Humidity: Less than or equal to 95%
2. Do not expose the lamp to: a. High temperatures b. Water, steam or damp conditions c. Corrosive, flammable liquids, or gaseous / explosive atmospheres
3. Do not abuse the cord. Never carry the lamp by the cord or pull the cord to disconnect the lamp. Keep the cord away from heat, oil or sharp objects
4. Disconnect your lamp when not in use.
5. Never attempt to disassemble or repair the lamp, unless you are a qualified electrician
6. CAUTION: Never leave the magnifier lens unattended in direct sunlight or where light can shine through it - This constitutes a fire hazard!