



PRODUCT INFORMATION

Item Number	911
Product Colour	Red/Black
Size Range	6-12
Primary Coating Polymer	Nitrile
Grip	Microfoam Nitrile
Abrasion Level	4

FEATURES

Recycled Nylon Enhancement: The first existing glove in our range to be enhanced with recycled nylon. Doubling down on our efforts to manufacture products from recycled sources where possible. 91% of the liner is made from recycled nylon, which equates to 48% of the total glove weight

Grip: The palm coating is infused with microfoam bubbles increasing resistance to oils and maximising grip in wet and oily handling environments

Abrasion Resistant: Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388

Flexibility: Strategically designed to offer optimum levels of flexibility and comfort without compromising protection

Closure: Elasticated knitted wrist provides a secure fit and keeps hands free from dirt and debris

Primary Coating Polymer: Nitrile

Environmental: Packed without the use of plastic, reducing the overall weight of packaging

Comfort: Seamless construction will not irritate hands

Unique Feature: SilverClear® glove formulated from silver, a powerful and proven antimicrobial agent that inhibits bacterial, fungal and viral growth. The additive will protect the gloves from microbial growth but also from mould and bad odours avoiding premature material degradation and discoloration.



SECTORS

Automotive • Construction and Utility • Engineering and Manufacturing • Warehousing, Transport, and Logistics • Waste Management and Local Authority

STANDARDS



PPE CAT II



4121X



STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

DISPOSAL INSTRUCTIONS

Dispose of the product responsibly in accordance with local regulations.

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

PACKING

10 pairs per bundle
60 pairs per case
85 cases per pallet

Size Outer Packaging Barcode

6	05010699842411
7	05010699841506
8	05010699841513
9	05010699841520
10	05010699841537
11	05010699842480
12	05010699858818

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555