

## PRODUCT INFORMATION

Item Number	882BK
Product Colour	Black
Size Range	6-10
Primary Coating Polymer	Polyurethane
Grip	Polyurethane Coating
Cut Score	C
Shelf Life	5 Years

## FEATURES

**Lining:** The 15 gauge liner has been specifically developed to ensure the most comfortable & secure feeling glove possible

**Abrasion Resistant:** Thin polyurethane coating in combination with the special fibre delivers great EN388 abrasion performance for extended glove life and reduced cost of ownership

**Cut Resistant:** Achieves cut level C according to EN388, for protection in high risk cut hazard applications.

**Environmental:** The liner is made from bio-based Dyneema® yarn (sustainable share allocated by mass balancing\*). The bio-based content in the liner constitutes a minimum of 50% of the total glove weight.

Packed without the use of plastic, reducing the overall weight of packaging

**Colour:** The black coating and liner hides dirt and contaminants to ensure that gloves are not discarded prematurely

**Cut Resistant:** Fine Dyneema® yarn offers superior cut resistance for a lightweight glove

**Primary Coating Polymer:** Polyurethane

**Abrasion Resistant:** Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388



## SECTORS

Automotive • Construction and Utility • Engineering and Manufacturing • Oil, Gas, and Renewables • Warehousing, Transport, and Logistics • Waste Management and Local Authority

## STANDARDS

**EN388 Protective gloves:** Mechanical hazards

**EN ISO 21420:2020 Protective gloves:** General requirements



4X42C

## CAUTION

**May contain latex in elasticated cuff which can cause allergic reactions, including anaphylactic response.**

## STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

**DISPOSAL INSTRUCTIONS**

Dispose of the product responsibly in accordance with local regulations.

**PACKING**

12 pairs per paper band  
48 pairs per case  
60 cases per pallet

Size	Outer Packaging Barcode
6	05010699999375
7	05010699999368
8	05010699999351
9	05010699999344
10	05010699999337

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555