

## PRODUCT INFORMATION

Item Number	DFA
Product Colour	Teal/Black
Size Range	6-11
Primary Coating Polymer	Polyurethane
Grip	Polyurethane Coating
Cut Score	B
Heat Resistance	Contact Heat Level 1

## FEATURES

**Lining:** 18 gauge seamless knitted liner is ultra-lightweight, breathable and highly flexible, ensuring ultimate comfort at all times

**Cut Resistant:** The liner, made with Dyneema® Diamond Technology, provides cut resistance without the use of abrasive materials

Achieves cut level B according to EN388, for protection in medium/low risk cut hazard applications

**Heat Resistant:** Achieves Level 1 for Contact Heat according to EN407. Can withstand temperatures of 100°C

**Flexibility:** Strategically designed to offer optimum levels of flexibility and comfort without compromising protection

**Closure:** Elasticated knitted wrist provides a secure fit and keeps hands free from dirt and debris

**Grip:** The resilient polyurethane palm coating is flexible and very hard wearing

**Primary Coating Polymer:** Polyurethane

**Fit:** Soft seamless knitted liner provides superior comfort for this level of protection

**Abrasion Resistant:** Achieves Level 2 for abrasion resistance as defined by European Standard EN388



## SECTORS

Automotive • Construction and Utility • Engineering and Manufacturing • Oil, Gas, and Renewables • Warehousing, Transport, and Logistics • Waste Management and Local Authority

## STANDARDS



PPE CAT II



2X42B



X1XXXX



## CAUTION

May contain latex in elasticated cuff which can cause allergic reactions, including anaphylactic response.

## STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

**DISPOSAL INSTRUCTIONS**

Dispose of the product responsibly in accordance with local regulations.

**PACKING**

10 pairs per polybag  
60 pairs per case  
60 cases per pallet

Size	Outer Packaging Barcode
6	05010699846860
7	05010699846419
8	05010699846426
9	05010699846433
10	05010699846440
11	05010699846877

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555