

PRODUCT INFORMATION

Item Number	GIO
Product Colour	Red/Black
Size Range	7-11
Typical Weight	32.50 g
Primary Coating Polymer	Nitrile
Grip	Dual Nitrile
Abrasion Level	4

FEATURES

Grip: Utilises two layers of nitrile coating to provide ultimate abrasion protection and gripping ability. The first layer is a soft and resilient full coating, allowing for excellent dexterity. The second layer which is a palm coating, is infused with microfoam bubbles increasing resistance to oils and maximising grip.

Abrasion Resistant: Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388

Comfort: The contoured design together with the soft seamless knitted liner and resilient nitrile coating ensures ultimate comfort with minimal hand fatigue in prolonged use

Closure: Elasticated knitted wrist provides a secure fit and keeps hands free from dirt and debris

Primary Coating Polymer: Nitrile

Environmental: Packed without the use of plastic, reducing the overall weight of packaging

Unique Feature: SilverClear® glove formulated from silver, a powerful and proven antimicrobial agent that inhibits bacterial, fungal and viral growth. The additive will protect the gloves from microbial growth but also from mould and bad odours avoiding premature material degradation and discoloration.

SECTORS

Construction and Utility • Engineering and Manufacturing • Oil, Gas, and Renewables • Warehousing, Transport, and Logistics • Waste Management and Local Authority



STANDARDS



PPE CAT II



4122X



STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

DISPOSAL INSTRUCTIONS

Dispose of the product responsibly in accordance with local regulations.

PACKING

10 pairs per paper band
60 pairs per case
50 cases per pallet

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

Size	Outer Packaging Barcode
7	05010699835475
8	05010699835482
9	05010699835499
10	05010699835505
11	05010699842046

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555