

PRODUCT INFORMATION

Item Number	PECT
Product Colour	Green/Black
Size Range	6-12
Primary Coating Polymer	Nitrile
Grip	Foamed nitrile
Cut Score	F
Heat Resistance	Contact Heat Level 1

FEATURES

Cut Resistant: Ultra-lightweight 18-gauge liner achieves the maximum levels of cut resistance according to EN388:2016, and excellent abrasion and tear resistance.

Environmental: Each glove contains a minimum of 13% recycled material (rPET)

Unique Feature: Flat nitrile reinforcement between the thumb and forefinger offers additional protection in an area that is highly susceptible to wear and tear

Lining: 18 gauge seamless knitted liner is ultra-lightweight, breathable and highly flexible, ensuring ultimate comfort at all times

Heat Resistant: Achieves Level 1 for Contact Heat according to EN407. Can withstand temperatures of 100°C

Cut Resistant: Achieves cut level F according to EN388, for protection in the highest risk cut hazard applications

Primary Coating Polymer: Nitrile

Environmental: Packed without the use of plastic, reducing the overall weight of packaging
Recycled PET Liner



FEATURES

Unique Feature: SilverClear® glove formulated from silver, a powerful and proven antimicrobial agent that inhibits bacterial, fungal and viral growth. The additive will protect the gloves from microbial growth but also from mould and bad odours avoiding premature material degradation and discoloration.

Tactile touchscreen compatible fingertips enable the wearer to use touch screen machinery or touch screen devices with precision and without the need to remove the glove. The Hydrophobic solution, which is applied through an intensive washing process, allows for a comprehensive and robust 3-Dimensional water resistant performance in wet and challenging conditions while maintaining maximum breathability.

Abrasion Resistant: Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388

SECTORS

Automotive • Construction and Utility • Engineering and Manufacturing • Oil, Gas, and Renewables • Waste Management and Local Authority

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555



STANDARDS



PPE CAT II



4X44F



X1XXXX



CAUTION

May contain latex in elasticated cuff which can cause allergic reactions, including anaphylactic response.

STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

PACKING

10 pairs per bundle
60 pairs per case
60 cases per pallet

DISPOSAL INSTRUCTIONS

Dispose of the product responsibly in accordance with local regulations.

Size	Outer Packaging Barcode
6	05010699859648
7	05010699859655
8	05010699859662
9	05010699859679
10	05010699859686
11	05010699859693
12	05010699999290

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555