

PRODUCT INFORMATION

Item Number	GLOG1
Product Colour	Blue/Black
Size Range	8-11
Primary Coating Polymer	Nitrile
Grip	Dual Nitrile
Lining	Unlined
Shelf Life	5 years

FEATURES

Grip: Utilises two layers of nitrile coating to provide ultimate abrasion protection and gripping ability. The first layer is a soft and resilient full coating, allowing for excellent dexterity. The second layer which is a palm coating, is infused with microfoam bubbles increasing resistance to oils and maximising grip.

Chemical Resistant: Achieves type A chemical resistance according to EN ISO 374-1, for protection against at least 6 different chemicals

Abrasion Resistant: Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388

Length: 34cm

Heat Resistant: Achieves Level 2 for Contact Heat according to EN407. Can withstand temperatures of 250°C

Primary Coating Polymer: Nitrile

EN ISO 374-5 Protection: Conforms with the requirements of EN ISO 374-5, for protection against bacteria & fungi

Fit: Combines tactility and protection meaning you no longer have to compromise on user comfort, safety or productivity

Chemical Resistant: Provides protection against a wide range of chemicals and cleaning agents

Food Safe: Suitable for food contact; all food types. Please refer to our online Food Compatibility Chart for full details



SECTORS

Automotive • Construction and Utility • Engineering and Manufacturing • Food Manufacturing and Preparation • Janitorial • Warehousing, Transport, and Logistics

STANDARDS

EN388 Protective gloves: Mechanical hazards

Tested to European Standards EN420, EN ISO 374-1, EN 374-4 & EN ISO 374-5

Tested in compliance with Commission Regulation (EU) No 10/2011 for Food contact

Tested to European standard EN407:2004



PPE CAT III



2777



4121X KLMNOPT



X2XXXX



For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

**CAUTION**

Contains accelerator chemicals which may cause Type IV skin irritation and contact dermatitis in sensitised individuals.

DISPOSAL INSTRUCTIONS

Dispose of the product responsibly in accordance with local regulations.

STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

PACKING

10 pairs per polybag
60 pairs per case
30 cases per pallet

Size	Outer Packaging Barcode
8	05010699847652
9	05010699847669
10	05010699847676
11	05010699847683

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555