

## PRODUCT INFORMATION

Item Number	GIOTH
Product Colour	Yellow/Black
Size Range	7-12
Cold Handling	Contact Cold Level 3
Lining	Fleecy
Shelf Life	5 Year

## FEATURES

**Lining:** Fleecy lining keeps hands warm and comfortable in cold conditions

**Colour:** High visibility colour improves visual awareness even in subdued light

**Grip:** Utilises two layers of nitrile coating to provide ultimate abrasion protection and gripping ability. The first layer is a soft and resilient full coating, allowing for excellent dexterity. The second layer which is a palm coating, is infused with microfoam bubbles increasing resistance to oils and maximising grip.

**Abrasion Resistant:** Achieves a maximum score of Level 4 for abrasion resistance as defined by European Standard EN388

**Primary Coating Polymer:** Nitrile

**Fit:** Soft seamless knitted liner provides superior comfort for this level of protection

**Unique Feature:** SilverClear® glove formulated from silver, a powerful and proven antimicrobial agent that inhibits bacterial, fungal and viral growth. The additive will protect the gloves from microbial growth but also from mould and bad odours avoiding premature material degradation and discoloration.

**Cold Hazards:** Provides great insulation against the cold

**Cold Contact:** Provides Cold Contact Level 3 performance according to EN 511

## SECTORS

Construction and Utility • Engineering and Manufacturing •  
Warehousing, Transport, and Logistics



## STANDARDS

**EN388 Protective gloves:** Mechanical hazards

**EN ISO 21420:2020 Protective gloves:** General requirements

**Tested to European standard EN511:2006**



PPE CAT II



4222X



03X



## CAUTION

**May contain latex in elasticated cuff which can cause allergic reactions, including anaphylactic response.**

## STORAGE INSTRUCTIONS

Store in dry conditions, away from direct sunlight and extreme heat. It is recommended to retain the packaging for reference. Always inspect gloves prior to use and do not use if damaged or showing signs of wear and tear.

## PACKING

6 pairs per paper band  
60 pairs per case  
24 cases per pallet

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555

#### DISPOSAL INSTRUCTIONS

Dispose of the product responsibly in accordance with local regulations.

#### OUTER PACKAGING



Size	Outer Packaging Barcode
7	05010699845108
8	05010699845115
9	05010699845122
10	05010699845139
11	05010699845146
12	05010699846730

For further technical information, please contact Customer Services on 0333 320 8550 or the Technical team on 0333 320 8555